

Arctic Silver 95Ri Recumbent Bike




Customer Support Services


PARTS MANUAL rev 01 May 2008


Description	Part No.
OPERATION MANUAL	M051-00K39-A119
POWER OPTION KIT 120V	GK39-00002-0002
POWER OPTION KIT 240/50V UK	GK39-00002-0004
POWER OPTION KIT 240V+AUS	GK39-00002-0005
POWER OPTION KIT 230/50V CON	GK39-00002-0006
HARDWARE BAG	GK39-00002-0008
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	 0017-00008-0204 0017-00008-0205 0017-00008-0206
SERVICE MANUAL	M051-00K39-A012




Language	Part No.	
	Console Assembly	Overlay/Bezel/ Switch Assembly
Eng	AK39-00133-0001	AK63-00165-0001
Eng Met	AK39-00133-0002	AK63-00165-0001
Ger Met	AK39-00133-0003	AK63-00165-0003
Spn Met	AK39-00133-0004	AK63-00165-0004
Jap Met	AK39-00133-0006	AK63-00165-0006
Frn Met	AK39-00133-0007	AK63-00165-0007
Itl Met	AK39-00133-0008	AK63-00165-0008
Dut Met	AK39-00133-0009	AK63-00165-0009
Por Met	AK39-00133-0010	AK63-00165-0010
Tur Met	AK39-00070-0014	AK63-00165-0014



Console Mounting Screws (4)
0017-00101-1744
Grips (2)
0K39-01005-0001
Console Support
AK39-00003-0002
Frame Post Bolts (4)
0017-00101-1756
Frame Post



Right Shroud
AK39-00031-0007
Decal
0K39-01066-0000
Shroud Screws (7)
0017-00101-1741
Crank Arm, RT
0K39-01042-0007
Screws (3)
0017-00101-1855
End Cap Screws (2)
0017-00101-1614
End Cap
AK39-00050-0005
Decal
0K51-01085-0001
Right Pedal
AK63-00263-0003
Pedal Strap (not shown)
0K63-01238-0003
Shroud Screws (4)
0017-00101-1741
Left Shroud
AK39-00031-0008
Decal
0K39-01066-0000
Left Pedal
AK63-00263-0004
Pedal Strap (not shown)
0K63-01238-0004
Crank Arm, LT
0K39-01042-0008
Screws (3)
0017-00101-1855



Intermediate
Pulley Belt
0K63-01066-0001
Screw
0017-00101-1193
Mounting Screw(2)
0017-00101-0975
Bracket
0K51-01036-0000
Screw
0017-00101-1193
Alternator Belt
0017-00009-0735
6V Battery
0017-00003-0685



Resistor Assembly
AK39-00020-0001
Washers (2)
0017-00104-0309
Resistor Retainer
0K39-01043-0000
Pan Screws (2)
0017-00101-1282
Resistor
100E-00002-0092
Hex Nuts (3)
0017-00103-0081
Mounting Bracket
0K39-01036-0000
Mounting Rod
0K63-01166-0000

Power Control Board Assembly
AK39-00022-0001






Alternator w/Pulley Assembly
AK63-00093-0000
Alternator Pulley
0K61-02500-0001
Alternator
0017-00009-0841
Locking Nut
0017-00103-0117
Washer
0017-00104-0044
Bolt
0017-00101-0956



Crank Arm Hub
0K63-01095-0001
Pulley Assembly
AK63-00051-0000
Pulley
0K63-01018-0000
Washers (3)
0017-00104-0458
Flywheel Screws (3)
0017-00101-1715
*Crankshaft & Bearing Kit
GK63-00002-0077
*Crankshaft
0K63-01012-0001
*Small Thrust Washer (2)
0K63-01129-0000
*Large Thrust Washer (2)
0K63-01129-0001
*Bowed Retainer Ring (2)
0017-00100-0243
Washer (2)
0017-00104-0409
*Needle Bearing (2)
0K63-01344-0000
*Small Snap Ring (2)
0017-00100-0241
Crank Arm Hub (2)
0K63-01095-0001
Bolt (2)
0017-00101-1705



Clutch Assembly
AK63-00026-0000
(not included in kit)
Magnet
118E-00001-0124
(not included in kit)
Delrin Washers (2)
0017-00104-0455
Retaining Ring
0017-00100-0242
Spacer (not available separately)
Intermediate Bearings (2, not available separately)
Intermediate Pulley
(not available separately)
Intermediate Shaft and Bearing Assembly Kit
GK63-00002-0007


Idler Bracket Assembly
AK63-00021-0000






Screws (4)
0017-00101-1745
End Caps (4)
0K19-01208-0001
Washers (8)
0017-00104-0461
Double-sided
Foam Tape (2)
0K19-01222-0000
Heart Rate Electrode
AK63-00014-0003
Handlebar w/Insert
AK39-00024-0002
Bushing Hole
0017-00042-0866
Screws (2)
0017-00101-1282
Seat Assembly
AK51-00023-0003
Tape (2)
0K19-01222-0000
Upper Flex Cable Clamp
0K19-01221-0000
Flat-Flex Cable
AK19-00082-0001
Cable Sleeve
0K19-01230-0000
Hex Bolts (4)
0017-00101-1749



Roller Shields (4)
0K51-01059-0001
Washer
0017-00104-0461
Spacers (4)
0K51-01044-0000
Locking Nuts (4)
0017-00103-0326
Washers (4)
0017-00104-0463
Washers (4)
0017-00104-0462
Screws (2)
0017-00101-1748
Lock Assembly
AK51-00053-0001
Bolts (4)
0017-00101-1743
Locking Nuts (8)
0017-00103-0325
Roller Assembly
AK51-00056-0001
Rollers, RT (2)
0K51-01034-0001
Rollers, LT (2)
0K51-01034-0002



Seat Assembly Frame
AK39-00036-0002
Screws (4)
0017-00101-1746
Washers (4)
0017-00104-0462
Front Stop Bracket
0K51-01062-0000
Plastic Shield
0K19-01185-0001
Split Clamp
0017-00042-0880
Pan Screw
0017-00101-1295
Push Mount Wire Clips (2)
0017-00042-0879


Accessory Tray
AK39-00052-0003
Seat Back
0K51-01055-0001
Seat Bottom
0K51-01054-0001
Washers (4)
0017-00104-0462
Mounting Screws (4)
0017-00101-1743


Extrusion Assembly
AK39-00027-0005
Bumper
0017-00041-0654
Stop Bracket
0K51-01061-0001
Screws (2)
0017-00101-1751
Locking Rack
0K51-01013-0002
Screws (2)
0017-00101-1750
Decal
0K51-01039-0001
Plastic Grommet2 (2)
0017-00042-1055
Bolts (2)
0017-00101-1183
Extrusion Seat Assy
AK39-00027-0005


Locking Assembly
AK51-00053-0001
TORX Screw
0017-00101-1742
Anti-Rattle Washer
0K51-01060-0001
Knob
AK51-00029-0001
Retainer Bearing
0K51-01011-0000
Handle Shaft
0K51-01007-0000
E-Ring
0017-00100-0018
Groove Pin
0017-00007-0245
Washer
0017-00104-0421
Compression Spring
0K51-01012-0000
Housing-Insert Assembly
AK51-00030-0001
Locking-Block Assembly
AK19-00147-0000


Rear Stabilizer
GK39-00002-0012
End Cap
0K63-01219-0001
Lock Nut
0017-00103-0273
Leveler
0017-00009-0795
Leveler Assembly
AK61-00035-0000
Pan Screws (2)
0017-00101-1747
Flat Washer
0K63-01041-0000
Wheel Assembly
AK63-00016-0001
Wheel Screw
0017-00101-1747
Wheel Insert
0K63-01039-0000



Cable Coax - AK32-00020-0001
Cable Power Ext - AK32-00078-0001